



# RPP051

2.5" Pico-ITX

User's Manual

## Copyright

This publication contains information that is protected by copyright. No part of it may be reproduced in any form or by any means or used to make any transformation/adaptation without the prior written permission from the copyright holders.

This publication is provided for informational purposes only. The manufacturer makes no representations or warranties with respect to the contents or use of this manual and specifically disclaims any express or implied warranties of merchantability or fitness for any particular purpose. The user will assume the entire risk of the use or the results of the use of this document. Further, the manufacturer reserves the right to revise this publication and make changes to its contents at any time, without obligation to notify any person or entity of such revisions or changes.

Changes after the publication's first release will be based on the product's revision. The website will always provide the most updated information.

© 2023. All Rights Reserved.

## Trademarks

Product names or trademarks appearing in this manual are for identification purpose only and are the properties of the respective owners.

## FCC and DOC Statement on Class A

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

## Notice:

1. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Shielded interface cables must be used in order to comply with the emission limits.

# Table of Contents

Chapter 1 - Introduction.....	6
Specifications .....	6
Dimensions .....	8
Block Diagram.....	8
Chapter 2 - Hardware Installations.....	9
Overview.....	9
Top View.....	9
Bottom View.....	9
Switch Setting.....	10
TDP Switch Setting (J3) .....	10
Pin Assignment .....	11
RTC Battery (J1) .....	11
12V DC IN (CN1).....	11
SMBus (J5) .....	12
Front Panel (J6).....	12
DIO (CN6) .....	13
USB2.0 (UBJ1).....	13
Front Audio (AUJ1).....	14
COM1 (TSJ1).....	14
LAN1 (ETCN2) .....	15
USB3.0 (UBCN1).....	15
DP++ (CN11).....	16
eDP (CN30).....	17
Expansion Slots.....	18
Installing the M.2 Module.....	18
Installing the SO-DIMM Module .....	20
Chapter 3 - BIOS Settings.....	22
Overview .....	22
Main.....	23
Advanced .....	23
CPU Configuration.....	24
Power & Performance .....	24
Power & Performance ▶ CPU- Power Management Control .....	25
Power & Performance ▶ GT- Power Management Control .....	25
PCH-FW Configuration .....	26
Trusted Computing.....	26
NCT5525D Super IO Configuration .....	27
NCT5525D Super IO Configuration ▶ Serial Port 1 Configuration .....	27
NCT5525D HW Monitor .....	28
Serial Port Console Redirection .....	28
Serial Port Console Redirection ▶ Console Redirection Settings.....	29
ACPI Settings.....	30
Network Stack Configuration.....	31
NVMe Configuration.....	32
DFI WDT Configuration.....	32
USB Power Control.....	33
Tls Auth Configuration .....	33
Chipset .....	34
System Agent (SA) Configuration .....	34

PCH-IO Configuration .....	35
PCH-IO Configuration ▶ PCI Express Configuration .....	35
PCH-IO Configuration ▶ SATA Configuration .....	36
PCH-IO Configuration ▶ HD Audio Configuration .....	36
Security .....	37
Secure Boot.....	37
Boot .....	38
Save & Exit .....	38
MEBX.....	39
Updating the BIOS.....	39
Notice: BIOS SPI ROM.....	39
Appendix A- Mating Connectors.....	40
The Mating Connectors List.....	40

## About this Manual

This manual can be retrieved from the website.

The manual is subject to change and update without notice, and may be based on editions that do not resemble your actual products. Please visit our website or contact our sales representatives for the latest editions.

## Warranty

1. Warranty does not cover damages or failures that arises from misuse of the product, inability to use the product, unauthorized replacement or alteration of components and product specifications.
2. The warranty is void if the product has been subjected to physical abuse, improper installation, modification, accidents or unauthorized repair of the product.
3. Unless otherwise instructed in this user's manual, the user may not, under any circumstances, attempt to perform service, adjustments or repairs on the product, whether in or out of warranty. It must be returned to the purchase point, factory or authorized service agency for all such work.
4. We will not be liable for any indirect, special, incidental or consequential damages to the product that has been modified or altered.

## About this Package

The package contains the following items. If any of these items are missing or damaged, please contact your dealer or sales representative for assistance.

- 1 RPP051 board
- Heat sink for -5 to 65°C (Height: 37.8mm)
- Heat sink for -30 to 80°C (Height: 37.8mm)

Note: Thermal solution will change to heat spreader as the product goes to mass production.

Note: The items are subject to change in the developing stage. The product and accessories in the package may not come similar to the information listed above. This may differ in accordance with the sales region or models in which it was sold. For more information about the standard package in your region, please contact your dealer or sales representative.

## Static Electricity Precautions

It is quite easy to inadvertently damage your PC, system board, components or devices even before installing them in your system unit. Static electrical discharge can damage computer components without causing any signs of physical damage. You must take extra care in handling them to ensure against electrostatic build-up.

1. To prevent electrostatic build-up, leave the system board in its anti-static bag until you are ready to install it.
2. Wear an antistatic wrist strap.
3. Do all preparation work on a static-free surface.
4. Hold the device only by its edges. Be careful not to touch any of the components, contacts or connections.
5. Avoid touching the pins or contacts on all modules and connectors. Hold modules or connectors by their ends.



### Important:

Electrostatic discharge (ESD) can damage your processor, disk drive and other components. Perform the upgrade instruction procedures described at an ESD workstation only. If such a station is not available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the system chassis. If a wrist strap is unavailable, establish and maintain contact with the system chassis throughout any procedures requiring ESD protection.

## Safety Precautions

- Use the correct DC / AC input voltage range.
- Unplug the power cord before removing the system chassis cover for installation or servicing. After installation or servicing, cover the system chassis before plugging in the power cord.
- There is danger of explosion if battery incorrectly replaced.
- Replace only with the same or equivalent specifications of batteries recommend by the manufacturer.
- Dispose of used batteries according to local ordinance.
- Keep this system away from humid environments.
- Make sure the system is placed or mounted correctly and stably to prevent the chance of dropping or falling may cause damage.
- The openings on the system shall not be blocked and shall be kept in distance from

other objects to make sure of proper air ventilation to protect the system from over-heating.

- Dress the cables, especially the power cord, so they will not be stepped on, in contact with high temperature surfaces, or cause any tripping hazards.
- Do not place anything on top of the power cord. Use a power cord that has been approved for use with the system and is compliant with the voltage and current ranges required by the system's electrical specifications.
- If the system is to be unused or stored for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
- If one of the following occurs, consult a service personnel:
  - The power cord or plug is damaged.
  - Liquid has penetrated the system.
  - The system has been exposed to moisture.
  - The system is not working properly.
  - The system is physically damaged.
- The unit uses a three-wire ground cable which is equipped with a third pin to ground the unit and prevent electric shock. Do not defeat the purpose of this pin. If your outlet does not support this kind of plug, contact your electrician to replace the outlet.
- Disconnect the system from the electricity outlet before cleaning. Use a damp cloth for cleaning the surface. Do not use liquid or spray detergents for cleaning.
- Before connecting, make sure that the power supply voltage is correct. The device is connected to a power outlet which should be grounded connection.



The system may burn fingers while running.

Wait for 30 minutes to handle electronic parts after power off.


## Chapter 1 - Introduction

### ► Specifications


<b>SYSTEM</b>	
Processor	13th Generation Intel® Core™ Processors Intel® Core™ i7-1365UE Processor, 10C/12T, 1.7GHz/4.9GHz, 15W Intel® Core™ i5-1345UE Processor, 10C/12T, 1.4GHz/4.6GHz, 15W Intel® Core™ i3-1315UE Processor, 6C/8T, 1.2GHz/4.5GHz, 15W Intel® Processor U300E, 5C/6T, 1.1GHz/4.3 GHz, 15W
Memory	One 262-pin SODIMM up to 32GB Single Channel DDR5 up to 4800MHz
BIOS	AMI SPI 256Mbit
<b>GRAPHICS</b>	
Controller	Intel® UHD Graphics
Feature	DirectX12, Open GL 4.6, Vulkan 1.2 HW Decode: AV1, AVC/H.264, MJPEG, HEVC/H.265, VP9, SCC HW Encode: MJPEG, AVC/H.264, HEVC/H.265, VP9, SCC
Display	1 x DP++ DP++: resolution up to 4096x2304 @ 60Hz 1 x eDP eDP: resolution up to 4096x2160 @120Hz
Dual Display	DP++ + eDP
<b>EXPANSION</b>	
Interface	1 x M.2 E key 2230 (PCIe x1/USB 2.0) 1 x M.2 B key 3042/2242 for storage (PCIe x2/USB 2.0/SATA 3.0) 1 x M.2 B key 3042/2242 for 5G/LTE module (PCIe x1/USB 3.2 Gen1/SATA 3.0), with one Nano SIM slot
<b>AUDIO</b>	Audio Codec Realtek ALC888S-VD2-GR
<b>ETHERNET</b>	Controller 1 x Intel® I226IT (only Core i7/i5 supports iAMT)
<b>REAR I/O</b>	
Ethernet	1 x 2.5GbE (RJ-45)
USB	2 x USB 3.2 Gen2
Display	1 x DP++ 1 x eDP

<b>INTERNAL I/O</b>	Serial	1 x RS-232/422/485 (1.27mm pitch)
	USB	2 x USB 2.0 (1.27mm pitch)
	Display	1 x eDP Connector
	Audio	1 x Line-out/Mic-in (1.27mm pitch)
	DIO	1 x 8-bit DIO (1.00mm pitch)
	SMBus	1 x SMBus (1.00mm pitch)
<b>WATCHDOG TIMER</b>	Output & Interval	System Reset, Programmable via Software from 1 to 255 Seconds
<b>SECURITY</b>	TPM	fTPM 2.0
	Type	Single 12V +/-10% DC
<b>POWER</b>	Connector	2-pin Terminal Block
	Consumption	Typical: 1365UE: 12V @ 0.7A (8.4Watt) Max.: 1365UE: 12V @ 5.58A (66.96Watt)
	RTC Battery	CR2032 Coin Cell
<b>OS SUPPORT</b> (UEFI Only)	Microsoft	Windows 10 IoT Enterprise (64-bit) Windows 11
	Linux	Linux
<b>MECHANISM</b>	Dimensions	2.5" Pico-ITX Form Factor 100mm (3.94") x 72mm (2.83")
	Height	PCB: 1.6mm Top Side: 16.34 mm Bottom Side: 9.47 mm
<b>ENVIRONMENT</b>	Temperature	Operating: -5 to 65°C, -30 to 80°C Storage: -40 to 85°C
	Humidity	Operating: 5 to 90% RH Storage: 5 to 90% RH
	MTBF	1365UE: 621,170 hrs @ 25°C; 428,483 hrs @ 45°C ; 268,117 hrs @ 65°C Calculation model: Telcordia Issue 4 Environment: GB, GC – Ground Benign, Controlled
<b>STANDARDS AND CERTIFICATIONS</b>	Certifications	CE, FCC Class B, RoHS

► Dimensions



► Block Diagram







# Chapter 2 - Hardware Installations

## ► Overview

### Top View




### Bottom View



- |                 |                               |
|-----------------|-------------------------------|
| 1 DP++          | 9 SPI                         |
| 2 TDP Switch    | 10 Front Panel                |
| 3 2.5G LAN      | 11 RTC Battery                |
| 4 USB3.2 Gen2   | 12 Tact switch for Clear CMOS |
| 5 COM1          | 13 SMBus                      |
| 6 SIM Card Slot | 14 USB2.0                     |
| 7 eDP           | 15 12V DC IN                  |
| 8 DIO           | 16 Buzzer                     |
|                 | 17 Front Audio                |



**Note:**  
**Tact Switch for Clear CMOS:**  
 Turn off the power. Press and hold the switch for 1 or 2 seconds and then turn the power back on.



Use the tip of an unfolded paper clip (or similar object with a sharp tip) to gently press the switch circled in red.

► **Switch Setting**

TDP Switch Setting (J3)



<b>Switch Setting</b>	TDP - Max Assured Power
<b>Note</b>	HW only, BIOS invalidate



<b>Switch Setting</b>	TDP - Base Power
<b>Note</b>	Both HW/BIOS is validate



<b>Switch Setting</b>	TDP - Min Assured Power
<b>Note</b>	HW only, BIOS invalidate




**Note:**

To enable the latest setting, please reset to validate.


► **Pin Assignment**

RTC Battery (J1)




Pin	Assignment	Pin	Assignment
1	RTC Signal	2	GND

12V DC IN (CN1)




Pin	Assignment	Pin	Assignment
1	DC_IN	2	GND

SMBus (J5)




Pin	Assignment
1	3VSB
2	GND
3	I2C0_CLK
4	I2C0_SDA
5	I2C0_INT

Front Panel (J6)




Pin	Assignment	Pin	Assignment
1	SIO_PWSIN#	2	3V3SB
3	GND	4	SUS_LED#
5	SYSRST#	6	HD_LED#

DIO (CN6)




Pin	Assignment
1	D_IOA7_C
2	D_IOA6_C
3	D_IOA5_C
4	D_IOA4_C
5	D_IOA3_C
6	D_IOA2_C
7	D_IOA1_C
8	D_IOA0_C
9	5VSB
10	GND

USB2.0 (UBJ1)




Pin	Assignment	Pin	Assignment
1	5V_USB2_56	2	5V_USB2_56
3	USB2_4_C_N	4	USB2_3_C_N
5	USB2_4_C_P	6	USB2_3_C_P
7	GND	8	GND
9	X	10	X

Front Audio (AUJ1)




Pin	Assignment	Pin	Assignment
1	MIC2_L	2	AGND_AUDIO
3	MIC2_R	4	X
5	LINE2_R	6	MIC2-JD
7	AGND_AUDIO	8	X
9	LINE2_L	10	LINE2-JD

COM1 (TSJ1)




Pin	Assignment	Pin	Assignment
1	MDCD1#	2	MSIN1
3	MSOUT1	4	MDTR1#
5	GND	6	MDSR1#
7	MRTS1#	8	MCTS1#
9	MRI1#	10	X

LAN1 (ETCN2)




Pin	Assignment	Pin	Assignment
P1	X	P2	X
P3	225_LAN2_MDIP3	P4	225_LAN2_MDIN3
P5	225_LAN2_MDIP2	P6	225_LAN2_MDIN2
P7	225_LAN2_MDIP1	P8	225_LAN2_MDIN1
P9	225_LAN2_MDIP0	P10	225_LAN2_MDIN0
L1	225_LED2_LINK_ACT#	L2	3V3SB
L3	225_LED2_1000#	L4	225_LED2_2500#

USB3.0 (UBCN1)



Pin	Assignment	Pin	Assignment
1	5V_USBA_12	2	USB2_1_C_N
3	USB2_1_C_P	4	GND
5	USB3_1_C_RXN	6	USB3_1_C_RXP
7	GND	8	USB3_1_C_TXN
9	USB3_1_C_TXP	10	5V_USBA_12
11	USB2_2_C_N	12	USB2_2_C_P
13	GND	14	USB3_2_C_RXN
15	USB3_2_C_RXP	16	GND
17	USB3_2_C_TXN	18	USB3_2_C_TXP


DP++ (CN11)



Pin	Assignment
1	DPA_LANE0_P_C
2	GND
3	DPA_LANE0_N_C
4	DPA_LANE1_P_C
5	GND
6	DPA_LANE1_N_C
7	DPA_LANE2_P_C
8	GND
9	DPA_LANE2_N_C
10	DPA_LANE3_P_C
11	GND
12	DPA_LANE3_N_C
13	DPA_AUX_SEL_COM
14	DP2_CEC
15	DPA_CLK_AUXP
16	GND
17	DPA_DATA_AUXN
18	DPA_HPD_R
19	GND
20	3V3




eDP (CN30)



Pin	Assignment	Pin	Assignment
1	X	21	LVDS_PANEL_PWR
2	+12V	22	LVDS_PANEL_PWR
3	+12V	23	LVDS_PANEL_PWR
4	+12V	24	GND
5	+12V	25	eDPB_AUXN
6	X	26	eDPB_AUXP
7	X	27	GND
8	DIMMING_1	28	eDPB_LANE0_C_P
9	BLONOFF_1	29	eDPB_LANE0_C_N
10	eDP_GND	30	GND
11	eDP_GND	31	eDPB_LANE1_C_P
12	eDP_GND	32	eDPB_LANE1_C_N
13	eDP_GND	33	GND
14	eDP_HPD_CON_1	34	eDPB_LANE2_C_P
15	GND	35	eDPB_LANE2_C_N
16	GND	36	GND
17	GND	37	eDPB_LANE3_C_P
18	GND	38	eDPB_LANE3_C_N
19	X	39	GND
20	LVDS_PANEL_PWR	40	X

► **Expansion Slots**


Installing the M.2 Module




- 1 M.2 E-Key
- 2 M.2 B-Key  
(PCIe x1/USB 3.2 Gen1/SATA 3.0)
- 3 M.2 B-Key  
(PCIe x2/USB 2.0/SATA 3.0)

Before installing the M.2 module into the M.2 socket, please make sure that the following safety cautions are well-attended.


1. Make sure the PC and all other peripheral devices connected to it has been powered down.
2. Disconnect all power cords and cables.
3. Locate the M.2 socket on the system board
4. Make sure the notch on card is aligned to the key on the socket.
5. Make sure the standoff screw is removed from the standoff.




Please follow the steps below to install the card into the socket.



**Step 1:**  
Insert the card into the socket at an angle while making sure the notch and key are perfectly aligned.




**Step 2:**  
Press the end of the card far from the socket down until against the stand-off.



**Step 3:**  
Screw tight the card onto the stand-off with a screw driver and a stand-off screw until the gap between the card and the stand-off closes up. The card should be lying parallel to the board when it's correctly mounted.


## Installing the SO-DIMM Module




1 DDR5 SO-DIMM

Before installing the memory module, please make sure that the following safety cautions are well-attended.

1. Make sure the PC and all other peripheral devices connected to it has been powered down.
2. Disconnect all power cords and cables.
3. Locate the SO-DIMM socket on the system board
4. Make sure the notch on memory card is aligned to the key on the socket.




«« DDR5 SO-DIMM




«« Socket Top View

Please follow the steps below to install the memory card into the socket.




**Step 1:**

Insert the memory card into the slot while making sure 1) the notch and the key are aligned, and 2) the non-connector end rises approximately 45 degrees horizontally. Press the card firmly into the socket while applying and maintaining even pressure on both ends.



**Step 2:**

Press the end of the card far from the socket down while making sure the retention notch and the clip align as indicated by the dotted line in the illustration. If the retention notch and the clip do not align, please remove the card and re-insert it. Press the card all the way down.



**Step 3:**

The clips snap automatically and abruptly to the retention notches of the card sounding a distinctive click, and lock the card in place. Inspect that the clip sits in the notch. If not, please pull the clips outward, release and remove the card, and mount it again.

## Chapter 3 - BIOS Settings

### ► Overview

The BIOS is a program that takes care of the basic level of communication between the CPU and peripherals. It contains codes for various advanced features found in this system board. The BIOS allows you to configure the system and save the configuration in a battery-backed CMOS so that the data retains even when the power is off. In general, the information stored in the CMOS RAM of the EEPROM will stay unchanged unless a configuration change has been made such as a hard drive replaced or a device added.

It is possible that the CMOS battery will fail causing CMOS data loss. If this happens, you need to install a new CMOS battery and reconfigure the BIOS settings.



#### Note:

The BIOS is constantly updated to improve the performance of the system board; therefore the BIOS screens in this chapter may not appear the same as the actual one. These screens are for reference purpose only.

#### Default Configuration

Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.

#### Entering the BIOS Setup Utility

The BIOS Setup Utility can only be operated from the keyboard and all commands are keyboard commands. The commands are available at the right side of each setup screen.

The BIOS Setup Utility does not require an operating system to run. After you power up the system, the BIOS message appears on the screen and the memory count begins. After the memory test, the message "Press DEL to run setup" will appear on the screen. If the message disappears before you respond, restart the system or press the "Reset" button. You may also restart the system by pressing the <Ctrl> <Alt> and <Del> keys simultaneously.

### Legends

Keys	Function
Right / Left arrow	Move the highlight left or right to select a menu
Up / Down arrow	Move the highlight up or down between submenus or fields
<Enter>	Enter the highlighted submenu
+ (plus key)/F6	Scroll forward through the values or options of the highlighted field
- (minus key)/F5	Scroll backward through the values or options of the highlighted field
<F1>	Display general help
<F2>	Display previous values
<F12>	Popup Boot Device List
<F9>	Optimized defaults
<F10>	Save and Exit
<Esc>	Return to previous menu

#### Scroll Bar


When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the <K> and <M> keys to scroll through all the available fields.

#### Submenu

When "►" appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press <Enter>.

► Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.



**System Date**

The date format is <month>, <date>, <year>. Press "Tab" to switch to the next field and press "-" or "+" to modify the value.

**System Time**


The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.

► Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.




**Important:**  
Setting incorrect field values may cause the system to malfunction.



▶ Advanced

CPU Configuration



**Intel (VMX) Virtualization Technology**

When this field is set to Enabled, the VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

**Hyper-threading**


Enables this field for Windows XP and Linux which are optimized for Hyper-Threading technology. Select disabled for other OSes not optimized for Hyper-Threading technology. When disabled, only one thread per enabled core is enabled.

**AES**

Enable / Disable AES (Advanced Encryption Standard)

▶ Advanced


Power & Performance





▶ Advanced

Power & Performance ▶ CPU- Power Management Control



**Turbo Mode**

Enable or disable turbo mode of the processor. This field will only be displayed when EIST is enabled.

**Config TDP Configurations**


Configure TDP settings

**C states**

Enable or disable CPU Power Management. It allows CPU to enter "C states" when it's idle and nothing is executing.

▶ Advanced

Power & Performance ▶ GT- Power Management Control




**RC6 (Render Standby)**

Check to enable render standby support.

▶ Advanced

PCH-FW Configuration



**ME State**

When this field is set to Disabled, ME will be put into ME Temporarily Disabled Mode.

**Manageability Features State**

Enable or disable Intel(R) Manageability features. This option disables or enables Manageability Features support in FW. To disable it, support platform must be in an unprovisioned state first.

**AMT BIOS Features**

When disabled, AMT BIOS features are no longer supported and user is no longer able to access MEBx Setup. This option does not disable manageability features in FW.

**ME Unconfig on RTC Clear**

When disabled, ME will not be unconfigured on RTC Clear.

**Firmware Update Configuration**

Configure Management Engine Technology Parameters.

▶ Advanced

Trusted Computing



**Security Device Support**


This field is used to enable or disable BIOS support for the security device such as an TPM 2.0 to achieve hardware-level security via cryptographic keys.

**Pending Operation**

Schedule an Operation for the security Device.  
Note: Your computer will reboot during restart in order to change state of security Device.


▶ Advanced

NCT5525D Super IO Configuration



▶ Advanced

NCT5525D Super IO Configuration ▶ Serial Port 1 Configuration



**Serial Port**


Enable or disable serial port.

**Electrical Interface Mode**

Select an optimal settings for Super IO Device.


▶ Advanced

NCT5525D HW Monitor



▶ Advanced

Serial Port Console Redirection




**Console Redirection**

By enabling Console Redirection of a COM port, the sub-menu of console redirection settings will become available for configuration as detailed in the following.

► Advanced

Serial Port Console Redirection ► Console Redirection Settings



Configure the serial settings of the current COM port.

**Terminal Type**

Select terminal type: VT100, VT100+, VT-UTF8 or ANSI.

**Bits per second**

Select serial port transmission speed: 9600, 19200, 38400, 57600 or 115200.

**Data Bits**

Select data bits: 7 bits or 8 bits.

**Parity**

Select parity bits: None, Even, Odd, Mark or Space.

**Stop Bits**

Select stop bits: 1 bit or 2 bits.

**Flow Control**

Select flow control type: None or Hardware RTS/CTS. Flow Control is for RS485 mode and is only supported by Serial Port 1 (COM1).

**VT-UTF8 Combo Key Support**

Enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals.

**Recorder Mode**

With this mode enabled only text will be sent. This is to capture Terminal data.

**Resolution 100x31**

Enables or disables extended terminal resolution

**Putty KeyPad**

Select FunctionKey and KeyPad on Putty.

## ▶ Advanced

## ACPI Settings

**Wake system from S5 via RTC**

When Enabled, the system will automatically power up at a designated time every day. Once it's switched to [Enabled], please set up the time of day – hour, minute, and second – for the system to wake up.


**State After G3**

Select between S0 State, and S5 State. This field is used to specify what state the system is set to return to when power is re-applied after a power failure (G3 state).

- **S0 State** The system automatically powers on after power failure.
- **S5 State** The system enter soft-off state after power failure. Power-on signal input is required to power up the system.

► **Advanced**

**Network Stack Configuration**



**Network Stack**

Enable or disable UEFI network stack. The following fields will appear when this field is enabled.

**IPv4 PXE Support**

Enable or disable IPv4 PXE boot support. If disabled, IPv4 PXE boot support will not be available.

**IPv4 HTTP Support**

Enable or disable IPv4 HTTP boot support. If disabled, IPv4 HTTP boot support will not be available.

**IPv6 PXE Support**

Enable or disable IPv6 PXE boot support. If disabled, IPv6 PXE boot support will not be available.

**IPv6 HTTP Support**

Enable or disable IPv6 HTTP boot support. If disabled, IPv6 HTTP boot support will not be available.

**PXE boot wait time**


Set the wait time in seconds to press ESC key to abort the PXE boot. Use either +/- or numeric keys to set the value.

**Media detect count**

Set the number of times the presence of media will be checked. Use either +/- or numeric keys to set the value.

▶ Advanced

NVMe Configuration




**NVMe Configuration**

NVMe configuration enables you to set the NVMe drives to either RAID mode or Non-RAID mode.

▶ Advanced

DFI WDT Configuration




**Watchdog Timer**

Enable or disable Watchdog Timer.



► Advanced

USB Power Control




**Server CA Configuration**

**5\_Dual:** Support system wake up from S3/S4 by USB KB&MS

**5V:** No support system wake up from S3/S4 by USB KB&MS

► Advanced


Tls Auth Configuration



**Server CA Configuration**

Press <Enter> to configure Server CA.


► Chipset



Please select a submenu and press Enter. The submenus are detailed in the following pages.

► Chipset

System Agent (SA) Configuration



**VMD setup menu**

VMD Configuration Settings


**PCI Express Configuration :**

**VT-d**

VT-d capability.

► Chipset

PCH-IO Configuration



**PCI Express Configuration**

PCI Express Configuration Settings

**SATA Configuration**

SATA Device Options Settings

**HD Audio Configuration**

HD Audio Subsystem Configuration Settings

► Chipset

PCH-IO Configuration ► PCI Express Configuration




Select one of the PCI Express channels and press enter to configure the following settings.

**LAN1, M.2-E, M.2-B(R0), M.2-B (R1)**

Control the PCI Express Root Port.

► Chipset

PCH-IO Configuration ► SATA Configuration



**SATA Controller(s)**

This field is used to enable or disable the Serial ATA controller.

**SATA Speed**


This field is used to select SATA speed generation limit: Auto, Gen1, Gen2 or Gen3.

**Ports and Hot Plug**

Enable or disable the Serial ATA port and its hot plug function.

► Chipset

PCH-IO Configuration ► HD Audio Configuration




**HD Audio**

Control the detection of the HD Audio device.

- **Disabled** HDA will be unconditionally disabled.
- **Enabled** HDA will be unconditionally enabled.

► Security




**Administrator Password**

Set the administrator password. To clear the password, input nothing and press enter when a new password is asked. Administrator Password will be required when entering the BIOS.

► Security

Secure Boot



**Secure Boot**

The Secure Boot store a database of certificates in the firmware and only allows the OSEs with authorized signatures to boot on the system. To activate Secure Boot, please make sure that "Secure Boot" is "[Enabled]", Platform Key (PK) is enrolled, "System Mode" is "User", and CSM is disabled. After enabling/disabling Secure Boot, please save the configuration and restart the system. When configured and activated correctly, the Secure Boot status will be "Active".

**Secure Boot Mode**

Select the secure boot mode – Standard or Custom. When set to Custom, the following fields will be configurable for the user to manually modify the key database.

**Restore Factory Keys**

Force system to User Mode. Load OEM-defined factory defaults of keys and databases onto the Secure Boot. Press Enter and a prompt will show up for you to confirm.


**Reset To Setup Mode**

Clear the database from the NVRAM, including all the keys and signatures installed in the Key Management menu. Press Enter and a prompt will show up for you to confirm.

**Key Management**

Enables expert users to modify Secure Boot Policy variables without full authentication.

► Boot



**Setup Prompt Timeout**

Set the number of seconds to wait for the setup activation key. 65535 (0xFFFF) denotes indefinite waiting.

**Bootup NumLock State**

Select the keyboard NumLock state: On or Off.

**Quiet Boot**

This section is used to enable or disable quiet boot option.

**Boot Option Priorities**


Rearrange the system boot order of available boot devices.



**Note:**

If "Boot option filter" of "CSM Configuration" is set to "UEFI and Legacy" or "UEFI only", and "Quiet Boot" is set to enabled, "BGRT Logo" will show up for configuration. Refer to the Advanced > CSM Configuration submenu for more information.

► Save & Exit



**Save Changes and Reset**

To save the changes, select this field and then press <Enter>. A dialog box will appear. Select Yes to reset the system after saving all changes made.

**Discard Changes and Reset**

To discard the changes, select this field and then press <Enter>. A dialog box will appear. Select Yes to reset the system setup without saving any changes.

**Restore Defaults**

To restore and load the optimized default values, select this field and then press <Enter>. A dialog box will appear. Select Yes to restore the default values of all the setup options.

**Boot Override**

Move the cursor to an available boot device and press Enter, and then the system will immediately boot from the selected boot device. The Boot Override function will only be effective for the current boot. The "Boot Option Priorities" configured in the Boot menu will not be changed.

- **Save Setting to file** Select this option to save BIOS configuration settings to a USB flash device.
- **Restore Setting from file** This field will appear only when a USB flash device is detected. Select this field to restore setting from the USB flash device.

► MEBX



**Intel(R) ME Password**

Select Intel(R) ME Password and press Enter.

A prompt that requires password input will show up.

► Updating the BIOS

To update the BIOS, you will need the new BIOS file and a flash utility. Please contact technical support or your sales representative for the files and specific instructions about how to update BIOS with the flash utility.

► Notice: BIOS SPI ROM

1. The Intel® Management Engine has already been integrated into this system board. Due to the safety concerns, the BIOS (SPI ROM) chip cannot be removed from this system board and used on another system board of the same model.
2. The BIOS (SPI ROM) on this system board must be the original equipment from the factory and cannot be used to replace one which has been utilized on other system boards.
3. If you do not follow the methods above, the Intel® Management Engine will not be updated and will cease to be effective.



**Note:**

- a. You can take advantage of flash tools to update the default configuration of the BIOS (SPI ROM) to the latest version anytime.
- b. When the BIOS IC needs to be replaced, you have to populate it properly onto the system board after the EEPROM programmer has been burned and follow the technical person's instructions to confirm that the MAC address should be burned or not.
- c. After updating unique MAC Address from manufacturing, NVM will be protected immediately after power cycle. Users cannot update NVM or MAC address.

## Appendix A- Mating Connectors

### ► The Mating Connectors List

Please refer to the following list of the mating connectors.

Function	Connector	Connector information	Rate output
eDP connector	CN30	STM, eDP CONN, 1*40P/0.5mm, F, G/F, BLACK, 90D, SMT, MSAK24025P40C	12V/5V/1A
USB2.0 header	UBJ1	V-STAR, PIN PLUG, 2*5, 1.27mm, H=5mm, 180D, SMD, SHY-JCL180810P	5V/1A
AUDIO header	AUJ1	V-STAR, PIN PLUG, 2*5, 1.27mm, H=5mm, 180D, SMD, SHY-JCL180810P	NA
COM1 header	TSJ1	V-STAR, PIN PLUG, 2*5, 1.27mm, H=5mm, 180D, SMD, SHY-JCL180810P	5VSB/0.5A
Front Panel header	J6	V-STAR, PIN PLUG 2*3, 1.27mm, H=5mm, 180D, SMD, SHY-JCL180806P	3V3/1A
SMBus header	J5	JST, BOX HEADER, 1*5P/1.0mm, F, NATURAL, 180D, SMT, BM05B-SRSS-TB1(LF)(SN)	3V/1A
DIO header	CN6	JST, BOX HEADER, 1*10/1.00mm,SMD,BM10B-SRSS-TB(LF)(SN)	5V/1A