


Board Layout and Jumpers



COM1/COM2 Serial Mode	JP1/ JP6	JP2/ JP8	JP3/ JP10
RS232 (default)	1-3 On 2-4 On	1-3 On 2-4 On	1-3 On 4-6 On
RS422	3-5 On 4-6 On	3-5 On 4-6 On	3-5 On 4-6 On
RS485	3-5 On 4-6 On	3-5 On 4-6 On	3-5 On 2-4 On

COM 1/2 RS232 Power	JP4/JP7
Standard RS232 (default)	1-3 & 2-4 On
RS232 with Power	3-5 & 4-6 On
DIO Power Voltage	JP17
5VDU (default)	1-2 On
5V	2-3 On

DIO Power Sginal	JP18 (DIO0~3) JP19 (DIO4~7)
DIO Power (default)	1-2 On
GND	2-3 On
Clear CMOS Data	JP5
Normal (default)	1-2 On
Clear CMOS Data	2-3 On

Mini PCIe Power Select	JP22
3VDU (default)	1-2 On
3V	2-3 On
Mini PCIe Signal Select	JP23
SATA (default)	1-2 On
PCIe	2-3 On
SATA Terminal Select	JP21
SATA3 (Default)	1-2 On
Mini PCIe/mSATA	2-3 On

Pin Assignment

LAN LED


Pin	Assignment	Pin	Assignment
1	LAN1_1000	2	LAN1_100
3	LAN1_Link_ACT	4	3V3DU
5	LAN2_1000	6	LAN2_100
7	LAN2_Link_ACT	8	3V3DU

COM Ports (COM 1~6)


Pin	Standard RS232	RS232 with Power	RS422 Full Duplex	RS485
1	DCD-	12V	RX+	Data+
2	RD	RD	RX-	Data-
3	TD	TD	TX+	N.C.
4	DTR-	DTR-	TX-	N.C.
5	GND	GND	GND	GND
6	DSR-	DSR-	N.C.	N.C.
7	RTS-	RTS-	N.C.	N.C.
8	CTS-	CTS-	N.C.	N.C.
9	RI-	5V	N.C.	N.C.

USB 2.0 Headers (USB 9/10, 11/12)

Pin	Assignment	Pin	Assignment
1	VCC	2	VCC
3	Data-	4	Data-
5	Data+	6	Data+
7	GND	8	GND
9	---	10	N.C.




Note:
COM 3~6 only support Standard RS232.




Front Panel

Pin	Assignment	Pin	Assignment
1	N.C.	2	LED Power
3	HDD Power	4	LED Power
5	Signal	6	Signal
7	Ground	8	Ground
9	Signal	10	Signal
11	N.C.	12	---



SMBus


Pin	Assignment	Pin	Assignment
1	3V3SB	2	GND
3	SMB_CLK	4	SMB_DATA
5	SMB_ALERT	6	GND



LPC

Pin	Assignment	Pin	Assignment
1	L_CLK	2	L_AD1
3	L_RST#	4	L_AD0
5	L_FRAME#	6	3V3
7	L_AD3	8	GND
9	L_AD2	10	---
11	SERIRQ	12	GND
13	5VSB	14	5V

Note:
LPC can also be used to connect to EXT-RS232/485 module.



Front Audio


Pin	Assignment	Pin	Assignment
1	Mic2-L	2	GND
3	Mic2-R	4	N.C.
5	Line2-R	6	Mic2-JD
7	GND	8	---
9	Line2-L	10	Line2-JD

Chassis Intrusion

Pin	Function	Pin	Function
1	Signal	2	GND


USB 3.1 Gen 1 (USB 5/6)

Pin	Assignment	Pin	Assignment
1	VCC	11	Data5+
2	USB3_RX5-	12	Data5-
3	USB3_RX5+	13	GND
4	GND	14	USB3_TX6+
5	USB3_TX5-	15	USB3_TX6-
6	USB3_TX5+	16	GND
7	GND	17	USB3_RX6+
8	Data6-	18	USB3_RX6-
9	Data6+	19	VCC
10	5V		




Digital I/O (DIO)

Pin	Function	Pin	Function
1	GND	2	+12V
3	DIO_7	4	+12V
5	DIO_6	6	GND
7	DIO_5	8	5V
9	DIO_4	10	5V
11	DIO_3	12	GND
13	DIO_2	14	5VDU
15	DIO_1	16	5VDU
17	DIO_0	18	GND
19	GND		



S/PDIF

Pin	Assignment	Pin	Assignment
1	5V	4	GND
2	---	5	Signal In
3	Signal Out		



DFI reserves the right to change the specifications at any time prior to the product's release. This QR may be based on editions that do not resemble your actual products. For more documentation and drivers, please visit the download page at go.dfi.com/CS650-C246, go.dfi.com/CS650-Q370, or via the QR codes to the right.



C246



Q370